


Camp Trailer

From *Mechanix Illustrated*, August 1956

For Reference Only... Do not use to build a trailer.

Check on Teardrop and Tiny Travel Trailers for up to date building information;

<http://www.mikenchell.com/forums>



CAMP TRAILER

This portable camp will take your whole family on week-end trips.

DO you like to go camping with your wife and kids? Or maybe you're the fellow who likes to go hunting or fishing? If you are like many others the expense of renting a camp or bungalow often makes this outdoor pleasure prohibitive.

Mr. Art Harvey of Brockway, Pa., has nicely solved this problem. Friday eve-

nings, after work, he wastes no time getting home. Cleans up, gets a bite, shoos the wife and three kids into the car and takes off for a state park or some other favorite spot to spend the week end. Does he worry about accommodations that he will find there? No—because behind his car he is pulling a camp trailer—one that he has constructed in his spare time.

It isn't a large trailer, in fact it is smaller than the average car. Yet it has all the camping conveniences that he needs. It is large enough for the whole


Kitchen canopy folds up for easy use. Note space under stove used for table storage.

Rear of trailer features ventilator on top, two reflectors, rear light and license plate.



120






family to sleep in. It has a built in kitchen, complete with water supply, ice box, food compartment, table and chairs, stove and a clothes closet. The trailer is 10 feet long x 4 feet wide x 4 feet 10 inches high. It is a perfect trailer for a man who wants to travel, or hunt and go fishing in.

The trailer body is constructed entirely out of wood—plywood sides with hardwood framing. It has traveled over 20,000 miles in the last couple of years, and it is just as sturdy now as the day it was built.


Start construction with the axle and wheel assembly. The I beam should be




56 in. long, and be sure the ends are square. Take two uprights, 1x4x11-in. steel plate, and the two spindles that fit the trailer wheels and trim them down to 11 inches.

On the I beam measure in on each end 4 in. and take the spring you are going to use on that side and lay it across the I beam so that the outside of the spring is on this line. Now take the U bolts and slip two of them over the spring, and mark as closely as possible where the holes are to come. Center punch and drill these holes slightly over size

Interior view of trailer shows the clothes closet, access door and left side window.





as you will find it hard to make a perfectly snug fit. Repeat this operation on the other end of the beam. When these holes are drilled and springs are tried, and they fit to your satisfaction, remove them for the time being. Now take the uprights and weld one on each end of the I beam. After the uprights are welded on solidly you weld on the braces for added strength. The angle iron base frame is welded together to give it greater strength and durability. Corners of the frame are cut at a 45° angle and welded as shown in the drawings. The crosspieces are butt welded in place. Their location is determined by the length of the car springs used for the trailer.

After the crosspieces are butt welded into place, the 6-in. triangular plates are clamped inside the angle formed by the crosspieces and the angle iron sides. The triangular plates are then welded into place. These plates go where the spring mounts are to be bolted to. Set the springs into place and mark and drill the mounting holes on the plates. Now, take the 3-in. channel iron and weld it directly in the center of the frame. Measure back from the end of the tongue a distance of 12 in. and with your torch burn a 1 1/4 in. hole in the center of the channel iron. This is where your trailer jack will go.

Drill the holes that will hold the 2x4 hardwood frame to the angle iron trailer frame. With a power drill, drill a number of 7/16-in. holes through the angle iron frame; this also includes the two crosspieces. The holes can be drilled about 18 to 24

in. apart. You now have the frame ready for the hardwood frame and plywood bed. The corners of the hardwood sides and ends are cut at 45°. These pieces are then clamped on to the frame for a good, even fit.

After the plywood floor is cut and attached to the frame paste the linoleum piece down on the plywood bed. The linoleum doesn't necessarily have to be a new piece as it is used for damp proofing the trailer and makes cleaning and scrubbing the bed a simple matter. The wheels can now be put on the trailer bed.

The trailer jack is next. Secure the 1½x18-in. long bolt; mill or grind a ⅞-in. flat on the entire length of one side of it. This flat face is for locking the jack in place so that it will not unscrew while the trailer is in motion; see detail drawing for correct procedure.




Compact arrangement of kitchen area shows stove, ice box, water tap, storage drawers.

LARGE-SCALE PLANS

will greatly simplify construction. Send \$1.00 to MECHANIX ILLUSTRATED Plans Service, Fawcett Building, Fawcett Place, Greenwich, Conn. Specify Plan No. HJ-26, Trailer.


The jack dolly can be secured through your hardware dealer. It is welded to the end of the bolt. Take the 1½-in. nut and drill a hole through it as shown. The hole is to be large enough to receive the ¼-in. locking pin.

Screw the bolt into the nut so that the dolly rests on the floor. When you are satisfied with the way it sets take the ¼-in. rod and bend it into a crank and weld it to the top of the screw. [Continued on page 183]



Camp Trailer

[Continued from page 125]



Interior view shows bunk arrangement. Although not spacious, it will sleep a small family.

If you wish to buy the trailer jack you will possibly find an ad in this magazine where you can purchase one. That also goes for the trailer hitch as it is best to buy a hitch and be on the safe side.

The two pieces of 1-in. chain are welded about 3 in. from the end of the tongue, one on each side of the channel iron; the ends of these chains are to be fastened to the back bumper of the car. A heavy duty chain snap is welded to the end of each chain. If you do not have the right type of back bumper it would be a good idea to fasten heavy duty eyes to clamp the chain snaps to. This is very important because if the trailer hitch happens to come lose while you are traveling the safety chains will hold it in place.

The easiest way to construct the trailer cabin is to lay out the plywood sides and cut them to the desired shape. After this is done the 1x3-in. hardwood frame can be laid out and cut to fit the sides. Follow the drawings for dimensions and details.

Build the clothes closet next. This can

[Continued on page 184]



... Supplement warning lights with universal-mounting

Accessory Gauges

BY STEWART-WARNER

You need more than warning lights for safe, efficient operation of your car's engine. A generator warning light only indicates that the generator is working, and an oil-pressure warning light tells you when the oil pressure is dangerously low. But with quality Stewart-Warner Gauges you always know your exact oil pressure — your exact amperage reading.

Stewart-Warner offers a complete line of gauges for every purpose — for cars, trucks, buses, tractors, boats and stationary engines.

See your dealer or write:

STEWART-WARNER

Instrument Division

Dept. V-86, 1840 Diversey Parkway, Chicago 14, Illinois

You Need No Tools Other

The (BU 996) MASTER Framing Rule Than...

To Frame A House!

It's a fact! Not only is it possible to figure the angle of cut and length of run, but when you arrive at the solution, your framing rule is folded ready for marking. You need no other tools . . . and we will guarantee that in a very short time you will be figuring complicated house framing problems, faster, more accurately than you have ever believed possible.

Retails at \$2.95

MASTER RULE MFG. CO. INC., MIDDLETOWN, N. Y.

Please send me literature on the Master Framing Rule.

My local hardware dealer is.....

My name is.....

Address.....

When Answering Advertisements, Please Mention MECHANIX ILLUSTRATED

Camp Trailer

[Continued from page 183]

be constructed as shown, or to suit your individual requirements.

When building the kitchen partitions be sure to measure each piece's location before you cut it to size.

You will note that the four sides of the ice box are 22½ in. high; front and back are 16 in. wide, the top sides 10 in. wide. Before nailing the front on, lay out the food compartment door and cut it out. Do not nail in the plywood bottom until the sheet metal core and bottom insulation is installed.

Lay out the ice box sheet metal piece for the back and top sides. When you have this piece cut and bent as shown, the rest of the pieces will not give you any serious trouble. The upper front piece is cut and soldered in place. Be sure that the entire length of each joint is soldered. Next, the bottom is cut and soldered into place.

The ice compartment is built last. It is made from a piece of 16-gauge sheet metal. This is a heavier gauge as the ice will set here and it will be subject to some sliding around while the trailer is in motion.

The 8½x12-in. piece of corrugated metal is placed on the bottom of the ice compartment; the cake of ice will rest on this. Since the metal is corrugated it will provide an easy escape for the melted ice water, also keep the drain from being covered over and trapping the water. You can now solder the copper tubing in place allowing it to stick out a couple of inches through the bottom of the ice box.

Depending on the kind of material you use, you may find it easier to install the core in the wood shell first and then put in the insulating material.

Cut and bend the sheet metal of the ice box door as shown. For insulating cork or some similar material can be used. Fasten the sheet metal with small wood screws; the rubber seal is either glued or nailed into place.

Before cutting the above pieces to size, set the ice box on the kitchen cabinet base on the left side and snug against the trailer side. This is a temporary set up only for measuring purposes. The distance should be 31 in. from the right side of the trailer to ice box. This is the space that the kitchen

cabinet is to occupy. If the distance is other than 31 in. then you must cut the kitchen cabinet pieces accordingly. The height will not change.

The water tank goes behind the ice box. A tank of galvanized sheet metal of the right dimensions can either be made or purchased. At the base of the tank on the right side drill a ½ in. hole and solder a ½ in. piece of copper tubing. Make the tubing long enough to clear the edge of the kitchen base. The copper tubing is bent so that it will line up with the hole in the kitchen cabinet upright. Solder a threaded fitting to the end of the tubing and screw on the faucet.

After all parts of your trailer are constructed and installed, and the outside painted with a good outdoor paint, you will find that you have a really compact weekend trailer that will soon repay in pleasure the time and money spent on it. •

Photography Today

[Continued from page 155]

bottom of your camera? The tripod hole never seems to be where it was the last time you used the camera. If you think it hasn't moved around, just take a look at the scratches near the tripod socket! A gadget to eliminate this frustrating and undignified behavior is the Zip-Grip manufactured by Burleigh Brooks of 10 West 40th Street, New York City.

The Zip-Grip consists of two parts—a small button about a quarter-inch thick, as wide as a half-dollar, with a ¼x20 stud in the middle. This part is screwed into the tripod socket of the camera and left there permanently. The other part of the Zip-Grip is screwed to the tripod.

To secure the camera to the tripod, a small lever on the tripod half is pushed, opening a set of jaws. The camera, with the mating half on the bottom, is then placed within the jaws and the lever pushed to the closed position.

Presto, your camera is locked to the tripod with nary a wiggle between camera and tripod. •

—R. B.